















# 10 ▶



# 11 ▶









# MODELL: AS15



13	502x360	1/2
12	306x308	1/2
11	293x124	2/2
10	300x136	2/2
9	300x136	2/2
8	380x180	2/2
7	346x134	2/2
6	487x352	1/2
5	174x352	2/2
4	346x370	2/2
3	346x370	2/2
2	520x389	1/2
1	520x389	1/2


4x	20x	16x	1x	20x	20x	1x	7x	8x
6x	1 kpl.	4x	6x	20x	2x	4x		







levá skříň/lavá skriňa

pravá skříň/skriňa

8▶




9▶









6▶

AS15





7▶



**1**






Vodící lišta zásuvky "PK3" na prvku 4 představuje levou skříňku. Při výběru správné skříňky přišroubujte vodítka k prvku 3 stejným způsobem.

Vodiaca lišta zásuvky "PK3" na prvku 4 predstavuje ľavú skrinku. Pri výbere správnej skrinky priskrutkujte vodidlá k prvku 3 rovnakým spôsobom.



levá skříň/ľavá skriňa




pravá skříň/skriňa

**2**

4/8

levá skříň/ľavá skriňa

pravá skříň/skriňa

**3****4****5**

5/8