



NÁVOD NA MONTÁŽ

TV-5040



①




②




③



①



②



③

